


PDP Bass Drum



PDP Bass Drum

Part Number Description

PDBDCHCR	PDP CX/LX BASS DRUM CLAW HOOK CHROME
PDACCX1020_***	PDP CX/MX/LX SPUR
PDAP0018	PDP BASS PILLOW 16-18"W/VELCRO
PDACTR375CR	TENSION ROD, TRUE-PITCH, 3.75"(6 PK)BASS
PDRU1011	PDP RUBBER BASS DRUM LUG GASKET
PDAC1014BD	PDP BASS DRUM LUG (NCV)

OPTIONS

*** REPLACE "___" WITH THE SIDE

"L", LEFT

"R", RIGHT

PDACCX1020L	PDP CX/MX/LX SPUR - LEFT SIDE
PDACCX1020R	PDP CX/MX/LX SPUR - RIGHT SIDE
PDSPRCR	PDP BASS DRUM SPUR SET (L/R) CHROME
PDSPRBK	PDP BASS DRUM SPUR SET (L/R) BLACK

