





PDHHBOA PDP Hi-Hat Stand




PDACBOAKEY



PDSP379



SP358



SP074

SP074

PDAC0007

PDAC0006

PDAC0005

PDAC0004


SP715

SP715

PDAC0022

PDAC0022

PDSP001HH



SP363

PDHHBOA PDP Hi-Hat Stand

Part Number	Description
PDACBOAKEY	3-WAY KEY FOR BOA PEDAL
PDSP001HH	PDP 1" TUBE JOINT BOLT AND WING NUT
PDAC0004	HEEL BRACKET, BOA SINGLE PEDAL
PDAC0005	HEEL FOR BOA PEDALS/HH
PDAC0006	FOOTBOARD CLAMP, BOA SINGLE
PDAC0007	SCREW, FTBD CLAMP, BOA SINGLE
PDAC0022	SCREW,HEEL PEDAL PLATE,BOA HH S&D PEDAL
DWSP074	DRUM KEY SCREW 1/4-20 X 9/16" W/ COLLAR
PDAC342	RUBBER FOOT (3 PACK)
DWSP356	FELT WASHER (HI HAT SEAT)
DWSP357	STANDARD UPPER TUBE ASSEMBLY FOR HI-HAT
DWSP358	21" STANDARD LENGTH UPPER ROD W/ NUT
DWSP363	LOWER SPRING ROD
DWSP374	HI HAT SPUR
PDSP379	PDP BRANDED DW STYLE CLUTCH BOA
DWSP381	METAL WASHER FOR HH CYMBAL SEAT
DWSP715	7/16" SCREW
PDAC781	PDP HINGED MEMORY LOCK - 3/4"
DWSP2004	6MM HI-HAT CLUTCH DRUM KEY SCREW
DWSP2047	HI HAT SEAT ASSY W/O FELT/WASH

